

Ascent Particle Filter Molecular Conductance Study

6 April 2009

Keith R. Olson and Kelsey A. Folgner
Space Materials Laboratory
Physical Sciences Laboratories

Randy M. Villahermosa
Advanced Programs
Missile Defense Space Systems

Prepared for:

Space and Missile Systems Center
Air Force Space Command
483 N. Aviation Blvd.
El Segundo, CA 90245-2808

Authorized by: Engineering and Technology Group


20090911256

APPROVED FOR PUBLIC RELEASE;
DISTRIBUTION UNLIMITED

This report was submitted by The Aerospace Corporation, El Segundo, CA 90245-4691, under Contract No. FA8802-09-C-0001 with the Space and Missile Systems Center, 483 N. Aviation Blvd., El Segundo, CA 90245. It was reviewed and approved for The Aerospace Corporation by G. F. Hawkins, Principal Director, Space Materials Laboratory; and D. C. Marvin, Principal Director, Research and Program Development Office. David E. Davis was the project officer for the Mission-Oriented Investigation and Experimentation (MOIE) program.

This report has been reviewed by the Public Affairs Office (PAS) and is releasable to the National Technical Information Service (NTIS). At NTIS, it will be available to the general public, including foreign nationals.

This technical report has been reviewed and is approved for publication. Publication of this report does not constitute Air Force approval of the report's findings or conclusions. It is published only for the exchange and stimulation of ideas.

A handwritten signature in dark ink, appearing to read 'David E. Davis', followed by the handwritten text 'for DD'.

David E. Davis
SMC/EA

REPORT DOCUMENTATION PAGEForm Approved
OMB No. 0704-0188

Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing this collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden to Department of Defense, Washington Headquarters Services, Directorate for Information Operations and Reports (0704-0188), 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to any penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number. **PLEASE DO NOT RETURN YOUR FORM TO THE ABOVE ADDRESS.**

1. REPORT DATE (DD-MM-YYYY) 06-04-2009		2. REPORT TYPE		3. DATES COVERED (From - To)	
4. TITLE AND SUBTITLE Ascent Particle Filter Molecular Conductance Study				5a. CONTRACT NUMBER FA8802-09-C-0001	
				5b. GRANT NUMBER	
				5c. PROGRAM ELEMENT NUMBER	
6. AUTHOR(S) Keith R. Olson, Kelsey A. Folgner, and Randy M. Villahermosa				5d. PROJECT NUMBER	
				5e. TASK NUMBER	
				5f. WORK UNIT NUMBER	
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) The Aerospace Corporation Physical Sciences Laboratories El Segundo, CA 90245-4691				8. PERFORMING ORGANIZATION REPORT NUMBER TR-2009(8550)-7	
9. SPONSORING / MONITORING AGENCY NAME(S) AND ADDRESS(ES) Space and Missile Systems Center Air Force Space Command 483 N. Aviation Blvd. El Segundo, CA 90245				10. SPONSOR/MONITOR'S ACRONYM(S) SMC	
				11. SPONSOR/MONITOR'S REPORT NUMBER(S)	
12. DISTRIBUTION/AVAILABILITY STATEMENT Approved for public release; distribution unlimited.					
13. SUPPLEMENTARY NOTES					
14. ABSTRACT Ascent particle filters on enclosures containing space hardware, such as electronics boxes, regulate venting of these enclosures during launch and ascent. While allowing venting to occur, these filters prevent the transport of particles into and out of the enclosures. Particle filters are primarily characterized with respect to the flow of gas through the filter; the conductance of out-gassed molecules is not quantified. This report documents a series of tests performed at The Aerospace Corporation's Space Materials Laboratory to measure the conductance of outgassed molecular contamination from a model contaminant across a typical particle filter as a function of outgassing arrival rate. The results herein show that a typical ascent particle filter significantly limits the conductance of molecular contamination.					
15. SUBJECT TERMS Particle filter, Venting, Conductance, Molecular contamination, Outgas					
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT Leave blank	18. NUMBER OF PAGES 35	19a. NAME OF RESPONSIBLE PERSON Keith Olson
a. REPORT UNCLASSIFIED	b. ABSTRACT UNCLASSIFIED	c. THIS PAGE UNCLASSIFIED			19b. TELEPHONE NUMBER (Include area code) (310)336-5056

Ascent Particle Filter Molecular Conductance Study

Keith R. Olson and Kelsey A. Folgner
Space Materials Laboratory
Material Processing and Evaluation Department

Randy M. Villahermosa
Space Systems Group

March 4, 2009

Keith.R.Olson@aero.org
310-336-5056

Ascent Particle Filter Molecular Conductance Study

Introduction

- Particle filters on enclosures containing space hardware (electronics boxes, etc.) provide venting during launch and ascent
- Filters are typically sized in the 5 to 10 μm effective filtration range
 - *Prevent the ingestion of particles into the assembly*
 - *Prevent the release of particles from the interior of the enclosure*
- Filters are most often characterized with respect to the flow of gas through the filter
 - *Conductance of outgassed molecules is not quantified*

Question to Answer: To what extent does a typical ascent particle filter limit the conductance of molecular contamination?



Ascent Particle Filter Molecular Conductance Study

Experiment Design

- Molecular conductance through a filter can be thought of in two ways:
 - **Effective Aperture Size:** *Size of the obstruction-free aperture that will pass molecules at the same rate as the filter*
 - **Mass Throughput:** *Percentage of mass per unit time that the filter can pass relative to an unobstructed target*
- Molecular conductance is considered to be a function of:
 - *Filter parameters (design, effective filtration size, material, etc.)*
 - *Macro dimensions of the filter (length, width, thickness)*
 - *Temperature of the filter*
 - *Rate of outgassing arrival*
- **Objective:** Measure the molecular conductance* across a typical filter as a function of outgassing arrival rate for a model contaminant (Diocetyl Phthalate)


* Molecular conductance measured for a Clausing beam profile, not for an omnidirectional pressure distribution. These experiments can be thought of as measuring the mass throughput attenuation of the ascent particle filter.




Ascent Particle Filter Molecular Conductance Study

Prototypical Ascent Filter

- Rigimesh 5 μm Filter from Pall Aeropower Corporation
 - Wire Thickness: 0.0014 inches
 - Filter Thickness: 0.006 inches



Macro photo of prototypical ascent filter.




SEM pictures of prototypical ascent filter. Magnification specified.

Prototypical sintered stainless steel wire mesh filter





Ascent Particle Filter Molecular Conductance Study

Chamber Configuration



The Carrier QCM, which is mounted on the Carrier, is identical to the Shroud QCM. For this study, it was located directly behind the Ascent Filter, with a gap of approximately 0.2 inches. Both QCMs were held at -75°C to collect all impinging flux, but not condense water.



Ascent particle filter mounted in chamber for testing

Ascent Particle Filter Molecular Conductance Study

Experiment Overview

- QCM Calibration
 - Calibrate the unobstructed Carrier QCM to the Shroud QCM to understand mass accumulation rate differences
- Install the filter approximately 0.2 in directly in front of the Carrier QCM
- 21 °C Single Filter Tests
 - Measure mass accumulation on the Carrier QCM & Shroud QCM with the single filter held at 21 °C (+2 °C, -1 °C) for each molecular flux of interest
- 5 °C Single Filter Tests
 - Measure mass accumulation on the Carrier QCM & Shroud QCM with the single filter held at 5 °C (+2 °C, -1 °C) for each molecular flux of interest

Filter testing performed at two filter temperatures and multiple molecular flux levels



Ascent Particle Filter Molecular Conductance Study

Single Filter Test Accumulation Rate* Summary

4/21/2008 QCM Calibration		4/29/2008 21°C Single Filter		5/14/2008 21°C Single Filter		5/28/2008 21°C Single Filter		5/28/2008 5°C Single Filter		5/29/2008 5°C Single Filter	
Background†	Carrier QCM	0.038 †	0.488	0.709	0.469	0.452	1.358				
	Shroud QCM	0.115 †	0.087	0.445	1.240	0.668	0.704				
Effusion Cell 30°C	Carrier QCM	1.060	0.091	0.212	16.8% §						
	Shroud QCM	1.409	0.894	1.260							
Effusion Cell 50°C	Carrier QCM	10.70	0.370	0.434	4.4% §						
	Shroud QCM	10.91	9.512	9.874							
Effusion Cell 60°C	Carrier QCM										
	Shroud QCM										
Effusion Cell 70°C	Carrier QCM	97.32	3.975								
	Shroud QCM	100.4	100.3								
Effusion Cell 80°C	Carrier QCM										
	Shroud QCM										

* All Rates in Angstroms per hour (Å/hr)

† Background rates measured with the effusion cell at 10°C and the shutter closed before all depositions each day (0Å deposited on each QCM)

‡ Measured after calibrations at 30°C, 50°C, and 70°C (Approximately 240Å deposited on each QCM)

§ Carrier QCM Rate as a percentage of the Shroud QCM Rate during the same deposition



Ascent Particle Filter Molecular Conductance Study

Summary

- To what extent does a typical ascent particle filter limit the conductance of molecular contamination?


21 °C Single Filter Tests

- The filter reduced the mass accumulation on the Carrier QCM to between 3.0% and 4.4% of the accumulation on the unobstructed Shroud QCM

5 °C Single Filter Tests

- The filter reduced the mass accumulation on the Carrier QCM to between 1.2% and 3.1% of the accumulation on the unobstructed Shroud QCM


Note: Data recorded with the effusion cell at 30 °C is difficult to interpret because the deposition rates were very low.



Appendix: Data Archive

Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive




Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive

Ascent Particle Filter Molecular Conductance Study
QCM Calibration
DOP on -75°C QCMs, Effusion Cell at 50°C

4/21/2008




* QCM data during deposition period.
For analysis purposes.

Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive

Ascent Particle Filter Molecular Conductance Study
QCM Calibration
DOP on -75°C QCMs, Effusion Cell at 70°C

4/21/2008




Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive

Ascent Particle Filter Molecular Conductance Study
QCM Calibration
DOP on -75°C QCMs, Background with Effusion Cell at 10°C

4/21/2008




Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive

Ascent Particle Filter Molecular Conductance Study
21°C Single Filter Test, Filter Shielding Carrier QCM
DOP on -75°C QCMS, Background with Effusion Cell at 10°C

4/29/2008




Ascent Particle Filter Molecular Conductance Study

Appendix. Data Archive

Ascent Particle Filter Molecular Conductance Study
21°C Single Filter Test, Filter Shielding Carrier QCM
DOP on -75°C QCMS, Effusion Cell at 30°C

4/29/2008




Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive

Ascent Particle Filter Molecular Conductance Study
21°C Single Filter Test, Filter Shielding Carrier QCM
DOP on -75°C QCMS, Effusion Cell at 50°C

4/29/2008




Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive

Ascent Particle Filter Molecular Conductance Study
21°C Single Filter Test, Filter Shielding Carrier QCM
DOP on -75°C QCMS, Effusion Cell at 70°C

4/29/2008




Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive

Ascent Particle Filter Molecular Conductance Study
21°C Single Filter Test, Filter Shielding Carrier QCM
DOP on -75°C QCMS, Background with Effusion Cell at 10°C

5/14/2008




Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive

Ascent Particle Filter Molecular Conductance Study
21°C Single Filter Test, Filter Shielding Carrier QCM
DOP on -75°C QCMS, Effusion Cell at 30°C

5/14/2008




Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive

Ascent Particle Filter Molecular Conductance Study
21°C Single Filter Test, Filter Shielding Carrier QCM
DOP on -75°C QCMS, Effusion Cell at 50°C

5/14/2008




Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive



Ascent Particle Filter Molecular Conductance Study
21°C Single Filter Test, Filter Shielding Carrier QCM
DOP on -75°C QCMS, Background with Effusion Cell at 10°C

5/28/2008



Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive




Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive

Ascent Particle Filter Molecular Conductance Study
21°C Single Filter Test, Filter Shielding Carrier QCM
DOP on -75°C QCMS, Effusion Cell at 70°C

5/28/2008




Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive

Ascent Particle Filter Molecular Conductance Study
21°C Single Filter Test, Filter Shielding Carrier QCM
DOP on -75°C QCMS, Effusion Cell at 80°C

5/28/2008




Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive


Ascent Particle Filter Molecular Conductance Study
5°C Single Filter Test, Filter Shielding Carrier QCM
DOP on -75°C QCMS, Background with Effusion Cell at 10°C

5/28/2008



Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive




Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive

Ascent Particle Filter Molecular Conductance Study
5°C Single Filter Test, Filter Shielding Carrier QCM
DOP on -75°C QCMS, Effusion Cell at 60°C

5/28/2008




Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive

Ascent Particle Filter Molecular Conductance Study
5°C Single Filter Test, Filter Shielding Carrier QCM
DOP on -75°C QCMS, Effusion Cell at 70°C

5/28/2008




Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive


Ascent Particle Filter Molecular Conductance Study
5°C Single Filter Test, Filter Shielding Carrier QCM
DOP on -75°C QCMS, Effusion Cell at 80°C

5/28/2008



Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive




Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive

Ascent Particle Filter Molecular Conductance Study
5°C Single Filter Test, Filter Shielding Carrier QCM
DOP on -75°C QCMS, Effusion Cell at 50°C

May 29, 2008




Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive

Ascent Particle Filter Molecular Conductance Study
5°C Single Filter Test, Filter Shielding Carrier QCM
DOP on -75°C QCMS, Effusion Cell at 60°C

May 29, 2008




Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive

Ascent Particle Filter Molecular Conductance Study
5°C Single Filter Test, Filter Shielding Carrier QCM
DOP on -75°C QCMS, Effusion Cell at 70°C

May 29, 2008




Ascent Particle Filter Molecular Conductance Study

Appendix: Data Archive

Ascent Particle Filter Molecular Conductance Study
5°C Single Filter Test, Filter Shielding Carrier QCM
DOP on -75°C QCMS, Effusion Cell at 80°C

May 29, 2008



Acknowledgements

The authors would like to thank Kenneth T. Luey for his valuable support and insight.

This work was supported under The Aerospace Corporation's Mission-Oriented Investigation and Experimentation (MOIE) program under Contract No. FA8802-09-C-0001 with the Space and Missile Systems Center.



The Aerospace Corporation
2310 E. El Segundo Boulevard
El Segundo, California 90245-4609
U.S.A.